

1: Power line Three-color lines connected with U, V and W phases/ yellow and green wires grounded Temperature control line 110°C thermistor two-phase connected with the temperature-control protector 2: Cooling water yielding (2 and 6 ends terminated with 8/6 hoses) 3:Pole change and dust removal pressure 0.2-0,3Mpa (6/4 hoses) 4: Air seal pressure 0.1-0.2Mpa (6/4 hoses) 5:Tool discharge and air feed pressure 0.70 MPa (6/4 hoses) 6: Cooling influent Pump lift 12m (avoid wrong connection) 7: Quantity of proximity switches Pole hanging and pole discharge NPN (normally open) N.O. Wiring method of the proximity switch Brown wire connected with +24VDC blue wire connected with 0VDC Signal load end connected with +24VDC/the other end connected with the black wire 8: Handle of the lifting sling Installation and use

Model	GDL120-30-18-5.5				
Voltage	220 V				
Power	2.2 kw				
Current	19.0 A				
Frequency	600 Hz				
Rotating speed	18000 rpm				
Pole number	4P				
Phase number	3				
Rotating direction	Rotate anticlockwise				
	from the shaft				
	extension end				
Tool holder	BT30 (Parfaite is				
	recommended)				
Blind rivet	BT30-15° (Parfaite is				
	recommended)				
Weight	25 KG				

PTC three-core							
thermistor parameter							
DC power supply	Maximum DC25V/100mA						
-20~25℃	≤300Ω						
≪90℃	≤750₽						
105°C	≤1650Ω						
110°C	Rated operating temperature						
115°C	≥3990₽						
≥125℃	≥12K Ω						
≤160℃	Maximum storage temperature						

Special warning:

1. The electric main shaft shall be installed at the clamped position; otherwise the bearing will be easily damaged!

The main shaft shall entirely stop before the tool changing. The manual tool changing button shall not act during the rotation of the shaft; otherwise it will easily result in the seizure of the shaft!
The compressed air shall be clean and dry, and the filter accuracy shall be 0.1micron! Air seal is normally open. It is recommended to use the two-level filter, and the filter accuracy is 0.5 micron/ 0.1 micron respectively. The air filter is installed with the self-discharge device.
It is required to set the frequency converter strictly according to the frequency-voltage curve of the electric shaft.

is		Number	Zoning	Modified document number	Signature	Date						Outline
		of places	-		-							
	Designed by			Standardized by			Phase mark			Weight	Scale	diagram
	Reviewed by	i										GDL120-30-18Z/5.5
	Processe by	d		Approved by			Total page(s)		Page			